



1. REMOVE THE TIMECLOCK FROM THE OLD FACEPLATE
2. DISCONNECT THE WIRING TO THE ROCKER SWITCH AT THE SWITCH.
3. DISCONNECT THE WIRING FROM THE THERMOSTAT AT THE INDIVIDUAL COMPONENTS AS SHOWN IN DIAGRAM #1146MEC.
4. REMOVE THE OLD FACEPLATE WITH THE OLD ROCKER SWITCH, THERMOSTAT AND THERMOSTAT WIRING.
5. INSTALL THE NEW FACEPLATE AND THE TIMECLOCK IN THE ORIGINAL POSITIONS.
6. WIRE THE ROCKER SWITCH AND THE SOLID STATE THERMOSTAT AS SHOWN IN DIAGRAM #1146RET

**HYDRO-QUIP**  
CORONA, CA 909.273.7575

Manufacture Notes: Ⓛ ON RELAY INDICATES CAPACITOR.

Dwg. No.  
**100TJ-DKQZ-F**

Drawn  
TDM  
Date  
01.22.98

Rev  
0

Wire Color Code

# RETRO FIT INSTRUCTIONS FOR SOLID STATE THERMOSTAT

B - Black	G - Green
Br - Brown	Bl - Blue
R - Red	V - Violet
O - Orange	W - White
Y - Yellow	Gr - Grey