



1. REMOVE THE TIMECLOCK FROM THE OLD FACEPLATE.
2. DISCONNECT THE WIRING TO THE ROCKER SWITCH AT THE SWITCH.
3. DISCONNECT THE WIRING FROM THE THERMOSTAT AT THE INDIVIDUAL COMPONENTS AS SHOWN IN DIAGRAM #1146MEC.
4. REMOVE THE OLD FACEPLATE WITH THE OLD ROCKER SWITCH, THERMOSTAT AND THERMOSTAT WIRING.
5. INSTALL THE NEW FACEPLATE AND THE TIMECLOCK IN THE ORIGINAL POSITIONS.
6. WIRE THE ROCKER SWITCH AND THE SOLID STATE THERMOSTAT AS SHOWN IN DIAGRAM #1146RET

HYDRO-QUIP
CORONA, CA 909.273.7575

Manufacture Notes: (C) ON RELAY INDICATES CAPACITOR.

Dwg. No.
100TJ-DKQZ-F

Drawn TDM
Date 01.22.98

Rev 0

Wire Color Code

RETRO FIT INSTRUCTIONS FOR SOLID STATE THERMOSTAT

Diagram No. **1146RET**

B - Black	G - Green
Br - Brown	BI - Blue
R - Red	V - Violet
O - Orange	W - White
Y - Yellow	GR - Grey