



NOTE #1: UNIVERSAL SYSTEM - CONVERT THE VOLTAGE OF THE DESIRED COMPONENT BY MOVING THE WHITE WIRE WITH THE COLOR CODED TERMINAL TO THE DESIRED VOLTAGE CONNECTION ON THE VOLTAGE CONVERSION BLOCK.

Drawn	Rev	Wire Color Code
MBS	02	
Date	09.17.09	B - Black G - Green
Diagram No.	2402	Br - Brown Bl - Blue
		R - Red V - Violet
		O - Orange W - White
		Y - Yellow Gr - Gray