



NOTE #1: UNIVERSAL SYSTEM - CONVERT THE VOLTAGE OF THE DESIRED COMPONENT BY MOVING THE WHITE WIRE WITH THE COLOR CODED TERMINAL TO THE DESIRED VOLTAGE CONNECTION ON THE VOLTAGE CONVERSION BLOCK.

Drawn MBS	Rev 1	Wire Color Code B - Black G - Green Bl - Blue BI - Blue R - Red V - Violet O - Orange W - White Y - Yellow Gr - Gray
Date 07.29.09	Diagram No. 2402	