



NOTE: Set pressure switch to 1.5 PSI

HYDRO-QUIP
CORONA, CA (909) 273-7575

Manufacture Notes: # 1 Install capacitor on coil of Contactor # 2 SET PRESSURE SWITCH TO 1.5 PSI

Dwg. No. **221F0-DK**

Drawn CDV
Date 02.18.99

Rev 0
Wire Color Code

B - Black	G - Green
Br - Brown	Bl - Blue
R - Red	V - Violet
O - Orange	W - White
Y - Yellow	Gr - Gray

HYDRO-QUIP DATE CODE ON PRESSURE SWITCH IS TO BE HIGHLIGHTED

Diagram No. **3054**