



HYDRO-QUIP
CORONA, CA (909) 273-7575

Manufacture Notes: Thermistor is to be placed underneath the manual reset hi-limit

Dwg. No.
242F0-DKQU6-BL

| | | | |
|-------------|------|----------|---|
| Drawn | TDM | Rev | 1 |
| Date | | 10.30.97 | |
| Diagram No. | 3513 | | |

Wire Color Code

| | |
|------------|------------|
| B - Black | G - Green |
| Br - Brown | BI - Blue |
| R - Red | V - Violet |
| O - Orange | W - White |
| Y - Yellow | Gr - Gray |