



Special Notes:
 #1 - Factory connected 120V. Move to 240V side of terminal block to convert circuit to 240V.
 #2 - Factory connected 120V. For 240V heater, unplug and reconnect to 240V receptacle.

Drawn By: BH	Date: 03.10.04
Hydro-Quip 13345 Estelle St. Corona, CA 92879	
Diagram No.: 2502C	Revision: 0
Short Code: XXXX	